

en/Okto-BL-Ctrl_3

6

LotharF
MikroKopter.de

Inhaltsverzeichnis

<u>1 Okto XL - Combi</u>	1/12
<u>1.1 power</u>	1/12
<u>1.2 Fast response with speed control</u>	1/12
<u>1.3 Other Features</u>	1/12
<u>1.4 Interface</u>	1/12
<u>1.5 mechanical data</u>	1/12
<u>1.6 delivery</u>	2/12
<u>2 Connections</u>	3/12
<u>2.1 Top</u>	3/12
<u>2.2 Bottom</u>	4/12
<u>2.3 Drills</u>	5/12
<u>2.4 Connect</u>	6/12
<u>3 Settings</u>	7/12
<u>4 Error codes</u>	10/12
<u>5 SW-Update</u>	11/12
<u>6 FAQ</u>	12/12
<u>6.1 Motor connection</u>	12/12
<u>6.2 Addressing</u>	12/12
<u>6.3 Buzzer</u>	12/12
<u>6.4 What is the gray 1-line cable for?</u>	12/12

1 Okto XL - Combi

1.1 power

- voltage : 10 to 30V -> 3 -7S Lipo
- 6 -layer PCB for optimal heat dissipation . 70u copper layers make the entire circuit board to the heat sink .
- current: up to 30A (per unit / peak) and 120A (Total / peak) - with appropriate cooling
- current limiting and temperature limiting
- Active freewheeling -> less power loss

1.2 Fast response with speed control

- rapid acceleration and braking of the propeller. Active and seamless braking gives the speed precisely and quickly on the new setpoint .
- return energy to the lipo when braking. Seamless transition from acceleration to braking
- significantly faster control with speed control

1.3 Other Features

- Integrated 12V voltage regulator for external LED-Supply
- Switchable LED output -> LEDs can flash in case of undervoltage
- Adjustable motor timing in several steps of 13-28° - compatible with the most common BL motors
- Adjustable switching frequency (10kHz - 20kHz)
- PPM to 500 Hz with simultaneous I2C - bus operation for telemetry and data logging
- Integrated 12V stabilization for LED lighting and other 12V appliances
- Switchable outputs for lighting -> ZB The blinking lights at low voltage
- Software adjustable direction of rotation
- Adjustable current and temperature limits
- Adjustable start-PWM
- Silent Start: test tone at startup can be disabled

1.4 Interface

- various interfaces for setpoint input (I2C, PPM (500Hz) , serial)
- Integrated current measurement measurement of the actual current and the used capacity on the MikroKopter control
- voltage and temperature measurement with data transmission to the ground station and data logging
- 11-bit resolution (2048 steps)
- various feedback to the [MikroKopter-FlightCtrl](#) (blocked motor , power limiting , etc.)
- extended configuration options (eg current limit , temperature limit , ...)
- two LEDs (OK and Error)
- all BLCs are already adressed (address 1-8)
- I2C bus access possible in PPM mode - for data logging and telemetry in PPM mode
- status messages are transmitted to the FC (engine blocks , Current, Self-test error ...)
- current measurement up to 75A per controller
- Convenient configuration of the BL controller via FC

1.5 mechanical data

- hole: 3mm
- Dimensions (W x H):


- weight: appr. 119g

1.6 delivery


- 1 SMD preassembled, programmed and tested board with 8 ESCs
- Lipo Power cable (open ends)
- 1-line cable for LED output control

2 Connections


2.1 Top



2.2 Bottom



2.3 Drills



[DXF \(CAD-File\)](#)

2.4 Connect

- FlightCtrl: by the 5-lines molex cable
- LiPo: LiPo plus / LiPo minus
- Stabilized 12V supply: +12V / -
- Adressing: The BL-Ctrls are already adressed
- LiPo-Voltage outputs (for low currents up to 3A)
- switched LED Stripes connections (4x)(switched by Out1 or Out2 of the flight control)
 - ◆ => Plug the gray connector cable int Out1 or Out2 of the FC to use switchable LED-Lights
=> A / -
- Motor 1-4
 - ◆ => Motor outputs 1-4 / A, B, C
=> You can either solder the cables on the top or the bottom side => the cable colour is marked for the standart MK-rotation direction
- Optional: Second Recom -> You can add a second voltage converter (for example 5V)
- Buzzer: connect the buzzer ba a 2-line cable to the "BuzZ" marked connections

3 Settings


IMPORTANT: To change the Settings of the BL-Ctrl V3.0 you need a Software version since V2.02a ([KopterTool](#), [FlightCtrl](#), [NaviCtrl](#))!

Normally you have not to change the settings! If you have to to it you can do it like described:

- open [KopterTool](#)
- press button "Strg" on your keyboard and hold it down.
- Then "click" "Settings" in the [KopterTool](#).

Now you will see the window of the BL-Ctrl V3.0.

INFO: only if you "click" and activate the single settings there you can change them.



BL-Ctrl settings

Address: 1

max. current: [A] 25

Temperature limiter 100

PWM scaling: 255

Start PWM 2

Current scaling: 64

Config

Reverse direction:

Frequency: 10kHz 20kHz

Dynamic speed control OFF:

Disable test tone:

Timing: 24*

Store in EEPROM:

Read Write

OK Restore Defaults

4 Error codes

The BL V3 performs a selftest during startup (test-tone). In case of an error, these are the blink codes:

- 1 "1" = Shortcut between A+ and B-
- 2 "2" = Shortcut between B+ and C-
- 3 "3" = Shortcut between C+ and A-
- 4 "E" = A doesn't go to high
- 5 "F" = B doesn't go to high
- 6 "G" = B doesn't go to high
- 7 "H" = A doesn't go to low
- 8 "I" = B doesn't go to low
- 9 "J" = C doesn't go to low
- 10 "K" = Overcurrent when switching to low
- 11 "L" = Overcurrent when switching to high
- 12 "Q" = Cross-circuit between low and high
- 15 overcurrent while starting the motor
- 16 error current measurement
- 17 error voltage measurement
- 18 error temperature measurement

5 SW-Update

If there is a new Software for the BL V3, here you can see how to update the BL: [Update](#)

6 FAQ

6.1 Motor connection

The motors can be connected either on the top-side or on the bottom-side. You can ignore the small (pre-)soldered points on the top-side.

6.2 Addressing

The BL-Ctrls are already addressed. This can't be changed on this coto.

6.3 Buzzer

The buzzer is connected via a cable

6.4 What is the gray 1-line cable for?

Plug the gray connector cable into Out1 or Out2 of the FC to use switchable LED-Lights

- [KategorieMK-Baugruppe/de](#)