

en/StickSetup/Mode3

11

LotharF
MikroKopter.de

This page as an **PDF-Document**? Click on that Symbol and wait a little moment... --->

[StickSetup](#)

MODE 3



- [deutsch](#)
- [français](#)

Here are the functions described which can be adjusted by different positions of the control stick in Mode 3.

Assignment of the sticks for MODE 3



Description of the stick assignment for MODE 3		
Function =>	Calibration of the ACC (One time necessary. The Kopter must stand straight.)	
Description of the stick assignment =>	Throttle up / Yaw right / Nick middle / Roll middle	

Function =>	Calibration of the Gyros (Before every Start and after disconnecting the power supply.)	
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll middle	
Function =>	Start to calibrate the Compass HINT: First pull Nick down. (The calibration is described here: Calibration of the compass)	
Description of the stick assignment =>	Throttle up / Yaw left / Nick down / Roll middle	

Function =>	Start the engines
Description of the stick assignment =>	Throttle down / Yaw right / Nick middle / Roll middle
Function =>	Stop of the engines
Description of the stick assignment =>	Throttle down / Yaw left / Nick middle / Roll middle



Function =>	Selection Setting 1
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll left
Function =>	Selection Setting 2
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll left



Function =>	Selection Setting 3
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll middle
Function =>	Selection Setting 4
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll right



Function =>	Selection Setting 5
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll right

