fr/StickSetup/Mode1

9

LotharF
MikroKopter.de

This page as an **PDF-Document**? Click on that Symbol and wait a little moment... --->

[StickSetup](#)

MODE 1

- 🇬🇧 english
- 🇩🇪 deutsch

Here are the functions described which can be adjusted by different positions of the control stick in Mode 1.

Assignment of the sticks for MODE 1

Description of the stick assignment for MODE 1		
Function =>	**Calibration of the ACC** (One time necessary. The Kopter must stand straight.)	
Description of the stick assignment =>	Throttle up / Yaw right / Nick middle / Roll middle	

	Calibration of the Gyros
Function =>	(Before every Start and after disconnecting the power supply.)
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll middle

	Start to calibrate the Compass
Function =>	**TIPP:** First pull Nick down. (The calibration is described here: Kompass kalibrieren)
Description of the stick assignment =>	Throttle up / Yaw left / Nick down / Roll middle

Function =>	Start the engines
Description of the stick assignment =>	Throttle down / Yaw right / Nick middle / Roll middle

Function =>	Stop the engines
Description of the stick assignment =>	Throttle down / Yaw left / Nick middle / Roll middle

Function =>	Selection Setting 1	
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll left	

Function =>	Selection Setting 2	
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll left	

Function =>	Selection Setting 3
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll middle

Function =>	Selection Setting 4
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll right

Function =>	Selection Setting 5
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll right