fr/StickSetup/Mode4

8

LotharF
MikroKopter.de

This page as an **PDF-Document**? Click on that Symbol and wait a little moment... --->

StickSetup

MODE 4

- english
- deutsch

Here are the functions described which can be adjusted by different positions of the control stick in Mode 4.

Assignment of the sticks for MODE 4



Description of the stick assignment for MODE 4		
Function =>	**Calibration of the ACC** (One time necessary. The Kopter must stand straight.)	
Description of the stick assignment =>	Throttle up / Yaw right / Nick middle / Roll middle	

Function =>	**Calibration of the Gyros** (Before every Start and after disconnectiong the power supply.)
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll middle



Function =>	**Start to calibrate the Compass** **TIPP:** First pull Nick down. (The calibration is described here: Kompass kalibrieren)
Description of the stick assignment =>	Throttle up / Yaw left / Nick down / Roll middle



Function =>	**Start of the engines**	
Description of the stick assignment =>	Throttle down / Yaw right / Nick middle / Roll middle	
Function =>	**Stop of the engines**	
Description of the stick assignment =>	Throttle down / Yaw left / Nick middle / Roll middle	

Function =>	**Selection Setting 1**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll left	
Function =>	**Selection Setting 2**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll left	

Function =>	**Selection Setting 3**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll middle	
Function =>	**Selection Setting 4**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll right	

Function =>	**Selection Setting 5**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll right	