en/MK-Parameter/User

16

LotharF
MikroKopter.de


Quick selection
Open the description -> click Button

Channels	Configuration	Stick	Looping	Altitude
Camera	Navi-Ctrl	Navi-Ctrl 2	Output	Misc
Gyro	User	Coupling	Mixer-SETUP	Easy Setup

This page as an **PDF-Document**?
Click on that Symbol and wait a little moment... --->

User

- deutsch


Parameterset 3 : Easy
Channels
Configuration
Stick
Looping
Altitude
Camera
Navi-Ctrl
Navi-Ctrl 2
Output
Misc
Gyro
User
Coupling
Mixer-SETUP
Easy Setup
Parameter 1:
Parameter 2:
Parameter 3:
Parameter 4:
Parameter 5:
Parameter 6:
Parameter 7:
Parameter 8:
0
P1 [Ch 5]=0
P2 [Ch 6]=0
P3 [Ch 7]=0
P4 [Ch 8]=0
P5 [Ch 9]=0
P6 [Ch 10]=0
P7 [Ch 11]=0
P8 [Ch 12]=0
Parameterset:
Expert view
3
Read
Write
OK
Help
Load...
Save...

This configuration parameter found in the official version of the FlightCtrl / NaviCtrl not apply. Here, no changes can be made. Therefore, all settings are left at 0.

The User parameters facilitate the handover to the MikroKopter for testing, special or debug versions.