

## **fr/StickSetup/Mode4**

8

LotharF  
MikroKopter.de

This page as an **PDF-Document**? Click on that Symbol and wait a little moment... --->

[StickSetup](#)

**MODE 4**



- [english](#)
- [deutsch](#)

Here are the functions described which can be adjusted by different positions of the control stick in Mode 4.



Assignment of the sticks for MODE 4



Description of the stick assignment for MODE 4		
<b>Function</b> =>	<b>Calibration of the ACC</b>  (One time necessary. The Kopter must stand straight.)	
<b>Description of the stick assignment</b> =>	Throttle up / Yaw right / Nick middle / Roll middle	

<b>Function</b> =>	<b>Calibration of the Gyros</b>  (Before every Start and after disconnecting the power supply.)	
<b>Description of the stick assignment</b> =>	Throttle up / Yaw left / Nick middle / Roll middle	
<b>Function</b> =>	<b>Start to calibrate the Compass</b>  <b>TIPP:</b> First pull Nick down.  (The calibration is described here: <a href="#">Kompass kalibrieren</a> )	
<b>Description of the stick assignment</b> =>	Throttle up / Yaw left / Nick down / Roll middle	



<b>Function</b> =>	<b>Start of the engines</b>	
<b>Description of the stick assignment</b> =>	Throttle down / Yaw right / Nick middle / Roll middle	
<b>Function</b> =>	<b>Stop of the engines</b>	
<b>Description of the stick assignment</b> =>	Throttle down / Yaw left / Nick middle / Roll middle	

Function =>	Selection Setting 1
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll left
Function =>	Selection Setting 2
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll left





Function =>	Selection Setting 3
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll middle
Function =>	Selection Setting 4
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll right



Function =>	Selection Setting 5
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll right

