en/StickSetup/Mode1

LotharF MikroKopter.de This page as an PDF-Document? Click on that Symbol and wait a little moment... --->

<u>StickSetup</u>


MODE 1

- <u>deutsch</u>
- III français

Here are the functions described which can be adjusted by different positions of the control stick in Mode 1.



Description of the stick assignment for MODE 1 Calibration of the ACC Function (One time => necessary. The Kopter must stand Nick (elevation) straight.) Throttle up Description / Yaw right of the stick assignment / Nick middle / => Roll middle Roll (aileron) Gier (yaw / rudder) mx-20



en/SuckSeu	ip/iviode i	09/21/24 14:46:17
Function =>	Start the engines	
Description of the stick assignment =>	Throttle down / Yaw right / Nick middle / Roll middle	(voiteval) Asian (aileron) Gier (yaw / rudder) mx-20 Roll (aileron) (aileron)
Function =>	Stop the engines	
Description of the stick assignment =>		Gier (yaw / rudder) Roll (aileron) Sest (through a least of the leas

en/SuckSett	р,о о. о .	03/21/24 14.40.17
Function =>	Selection Setting 1	
	Throttle up / Yaw left / Nick middle / Roll left	(incite value) Asing the contraction of the contrac
Function =>	Selection Setting 2	
Description of the stick		Gier (yaw / rudder) Roll (aileron) Gas (throttle)

Function =>	Selection Setting 3	
of the stick	Throttle up / Yaw left / Nick up / Roll middle	Gier (yaw / rudder) Roll (aileron) Ses Control Contro
Function =>	Selection Setting 4	
Description of the stick	1	Gier (yaw / rudder) Roll (aileron) Sep

