

# **en/StickSetup/Mode1**

19

LotharF  
MikroKopter.de

This page as an **PDF-Document**? Click on that Symbol and wait a little moment... --->

[StickSetup](#)

**MODE 1**

- [deutsch](#)
- [français](#)

Here are the functions described which can be adjusted by different positions of the control stick in Mode 1.



Description of the stick assignment for MODE 1

<p><b>Function</b> =&gt;</p>	<p><b>Calibration of the ACC</b>  (One time necessary. The Kopter must stand straight.)</p>
<p><b>Description of the stick assignment</b> =&gt;</p>	<p>Throttle up / Yaw right / Nick middle / Roll middle</p>





<p><b>Function</b> =&gt;</p>	<p><b>Calibration of the Gyros</b>  (Before every Start and after disconnecting the power supply.)</p>
<p><b>Description of the stick assignment</b> =&gt;</p>	<p>Throttle up / Yaw left / Nick middle / Roll middle</p>



<p><b>Function</b> =&gt;</p>	<p><b>Start to calibrate the Compass</b>  <b>Hint:</b> First pull Nick down.  (The calibration is described here: <a href="#">Calibration of the compass</a>)</p>
<p><b>Description of the stick assignment</b> =&gt;</p>	<p>Throttle up / Yaw left / Nick down / Roll middle</p>



<p><b>Function</b> =&gt;</p>	<p><b>Start the engines</b></p>	
<p><b>Description of the stick assignment</b> =&gt;</p>	<p>Throttle down / Yaw right / Nick middle / Roll middle</p>	
<p><b>Function</b> =&gt;</p>	<p><b>Stop the engines</b></p>	
<p><b>Description of the stick assignment</b> =&gt;</p>	<p>Throttle down / Yaw left / Nick middle / Roll middle</p>	

Function =>	Selection Setting 1
<p><b>Description of the stick assignment =&gt;</b></p>	<p>Throttle up / Yaw left / Nick middle / Roll left</p>
Function =>	Selection Setting 2
<p><b>Description of the stick assignment =&gt;</b></p>	<p>Throttle up / Yaw left / Nick up / Roll left</p>



<p><b>Function</b> =&gt;</p>	<p><b>Selection</b> <b>Setting 3</b></p>
<p><b>Description of the stick assignment</b> =&gt;</p>	<p>Throttle up / Yaw left / Nick up / Roll middle</p>



<p><b>Function</b> =&gt;</p>	<p><b>Selection</b> <b>Setting 4</b></p>
<p><b>Description of the stick assignment</b> =&gt;</p>	<p>Throttle up / Yaw left / Nick up / Roll right</p>



Function =>	Selection Setting 5	
<p><b>Description of the stick assignment</b> =&gt;</p>	<p>Throttle up / Yaw left / Nick middle / Roll right</p>	 <p>The image shows a Spektrum MX-20 transmitter. The left stick is labeled 'Nick (elevation)' with a vertical double-headed arrow. The right stick is labeled 'Gas (throttle)' with a vertical double-headed arrow. A horizontal double-headed arrow between the sticks is labeled 'Gier (yaw / rudder)'. Another horizontal double-headed arrow below the sticks is labeled 'Roll (aileron)'. The transmitter has a central LCD screen displaying 'MODE 1'. Other controls include 'ESC' and 'SET' buttons, and various knobs and switches at the top.</p>