en/StickSetup/Mode3

11

LotharF
MikroKopter.de

This page as an **PDF-Document**? Click on that Symbol and wait a little moment... --->

StickSetup

MODE 3

- deutsch
- français

Here are the functions described which can be adjusted by different positions of the control stick in Mode 3.

Assignment of the sticks for MODE 3



Description of the stick assignment for MODE 3		
Function =>	**Calibration of the ACC** (One time necessary. The Kopter must stand straight.)	
Description of the stick assignment =>	Throttle up / Yaw right / Nick middle / Roll middle	

Function =>	**Calibration of the Gyros** (Before every Start and after disconnecting the power supply.)
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll middle



Function =>	**Start to calibrate the Compass** **HINT:** First pull Nick down. (The calibration is described here: Calibration of the compass)
Description of the stick assignment =>	Throttle up / Yaw left / Nick down / Roll middle



Function =>	**Start the engines**
Description of the stick assignment =>	Throttle down / Yaw right / Nick middle / Roll middle



Function =>	**Stop of the engines**
Description of the stick assignment =>	Throttle down / Yaw left / Nick middle / Roll middle



Function =>	**Selection Setting 1**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll left	
Function =>	**Selection Setting 2**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll left	

Function =>	**Selection Setting 3**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll middle	
Function =>	**Selection Setting 4**	
Description of the stick assignment =>	Throttle up / Yaw left / Nick up / Roll right	

Function =>	Selection Setting 5	
Description of the stick assignment =>	Throttle up / Yaw left / Nick middle / Roll right	